

## MAINTENANCE SCHEDULE

2006 - 2008 Range Rover

Owner's` Name:									
Date:	RO#:								
MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	OIL	O&F	#1	O&F	OIL	O&F	#2
	TIME (Months)	6	12	18	24	30	36	42	48
	<ul><li>MILES (Thousands)</li><li>KM (Thousands)</li></ul>	7.5 12	15 24	22.5 36	30 48	37.5 60	45 72	52.5 84	60 96
● "Nominal" distance values for normal driving. See Passport to Service for additional information.									
1. VEHICLE INTERIOR		dooper							
Reset the Service Interval Indicator									
Check operation of all lights, warning indicators and horn									
Check operation of front/rear wiper washer systems. Check blades									
Replace pollen filter									
Check condition and security of seats and seat belts									
2. VEHICLE EXTERIOR									
Anti-corrosion check. Use Corrosion Perforation Form									
Lubricate top edge door seals									
3. ENGINE COMPARTMENT									
Check battery condition, fill electrolyte, clean terminals									
Inspect serpentine drive belts and if equipped Supercharger belt									
Replace drive belts (at 150k mi)∗									
Replace Supercharger drive belt (if equipped) (at 105k mi)★									
Check and top-up brake, PAS and windshield washer fluid									
Change brake fluid (3 years)									
Check coolant level and freeze protection level									
Change engine coolant (10 years) ★									
Replace spark plugs (at 105k miles) *									
Replace air-cleaner element <b>∗</b>									
Replace fuel filter (at 150k mi) ★									
4. UNDER VEHICLE									
Change engine oil and replace filter									
Remove road wheels									
Inspect for brake pad wear, caliper leaks and disc condition									
Check adjustment of electric park brake									
Check tire pressures condition and tread depth									
Lubricate wheel centers.									
Install road wheels to opposite side of the vehicle – except uni-directional tires which install on same side									
Inspect for under vehicle fluid leaks									
Inspect condition/operation of suspension and steering components, boots and drive axles									
Inspect brake, fuel lines, PAS hoses and unions for correct routing and damage									
Change automatic transmission fluid and filter (10 years or 150k miles) *									

Labor cost not included in scheduled time

Change transfer gearbox oil (75k and 150k miles) ★

Change front and rear axle oil (10 years) ★

ROAD TEST

Road test vehicle

Change electronic rear differential oil (75k and 150k miles) ★

5. REMEDIAL WORK/SERVICE CAMPAIGN NEEDED

If fault lamps illuminated use T4 to find the faults and report

Select LOW range, move vehicle 60 ft and select HIGH

Record performance of Service in Passport to Service

## **NOTIFICATION OF SERVICE REQUIREMENTS:**

- Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.

Yes/No

Yes/No

Yes/No Yes/No

Yes/No

Yes/No

Yes/No

Yes/No

♦ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule. LRNA 7/26/2007